ASSEMBLY INSTRUCTION FOR TV TABLE 2304/16ZA

FIGURE 1



1
Turn TV table top upside on a soft and even surface as in Figure 1

2
Unscrew the Bolt and washer from legs (left side) with the help of spanner provided ; attach the leg marked 'no.' to base marked 'no.' so on as in figure 2

FIGURE 2



3
Unscrew the Bolt and washer from legs (Right side) with top help of spanner provided; attach the leg marked 'No.' so on as in Figure 3

4
Tighten to ensure no play in legs assembled Now turn Side Table in upright position as in figure 4.

FIGURE 3



5
Now your TV table is Ready to use

Care and Maintenance

1
For General cleaning use a dry cloth do not use wet cloth,soap,detergent,aerosol sprays and polish on the product.

FIGURE 4



2
Do Not place hot or cold items directly on the surface. Use of Placement is recommended to avoid marks.

3
This Product is manufactured in solid hardwood and is made for indoor use.