


Article Number :- 3017/15




Ax1




Bx1




Cx3



Dx3




Ex20



Fx20



Gx1



Carefully place the table top upside down on a soft surface like a carpet or blanket to prevent scratches, align the holes and attach the leg securely using bolts (E) and washers (F), tightening them with the allen key (G). Refer to the image for proper alignment and assembly.

